## INSTALLATION INSTRUCTIONS HTLYM0204

#### **Parts**

A: Wood tubes A(3pcs)

B: Wood tubes B(3pcs)

C: Wood tubes C(3pcs)

D: Body

E: Socket

F: Shade

G: Socket ring

H: Bulb(not included)

#### STEPS:

- 1) Carefully remove all parts from package and make sure no parts are missing
- 2) Screw wood tubes (C) onto body (D) in a clockwise direction. Then screw tube
  - (B) on to tube (C) and tube (A) on to tube
  - (B) in the same way.
- 3)Place shade (F) onto the socket (E) and lock it with socket ring (G).
- 4)Screw the bulb (H) into the socket (E).

# Slighly adjust on shade and connection hardware to set it level which may came compressed during transportation.

### IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

