

## ASSEMBLY INSTRUCTION

Product Name: **HAISLEY COUNTER TABLE**




### PARTS LIST

Before you begin, please layout all parts and ensure you have the correct count.

NO.	DESCRIPTION	QUANTITY	ILLUSTRATION
1	Table Top	1	
2	Top Support	2	
3	Table Leg L/R	4	
4	Stretcher	2	
5	H Rail	2	
6	Cross Bar	1	
A	JCBB M8 x 30mm + S/W 5/16" + F/W 5/16" x 22mm	8	
B	Allen Key M5	1	
C	JCBC M6 x 35mm + S/W M6 + F/W M6 x 19mm	8	
D	JCBC M6 x 40mm + S/W M6 + F/W M6 x 13mm	2	
E	Allen Key M4	1	
F	FH Screw #8 x 38mm	8	
G	Wood Dowel M8 x 25mm	4	

# ASSEMBLY INSTRUCTIONS

STEP	DESCRIPTION	ILLUSTRATION
1	<p>Slot in Table Leg (3L &amp; 3R) into both Top Support (2). Then, fix JCBB Bolt (A) and tighten it by using Allen Key (B). <b>Do not fully tighten the bolts.</b></p>	
2	<p>Slot in both Stretcher (4) and H Rail (5) into the Table Leg (3L &amp; 3R). Then, slot in the other Table Leg (3R &amp; 3L) into the Top Support (2) as shown.</p>	
3	<p>Fix JCBC Bolt (A) into Top Support (2). Use Allen Key (B) to tighten the bolts. Fix FH Screw (F) into H Rail (5) and Stretcher (4) tighten it by using screwdriver (not provided). <b>Do not fully tighten the bolts and screws.</b></p>	
4	<p>Place the Table Top (1) upside down on a soft surface to avoid any scratches or damages to the product and fix Wood Dowel (G) into the Top Support (2). Then, fix the Top Support (2) into the designated hole of Wood Dowel (6) as shown.</p>	

<p>5</p>	<p>Fix the JCBC Bolt (C) into Top Support (2) and tighten by using Allen Key (E). <b>Do not fully tighten the bolts.</b></p>	
<p>6</p>	<p>Fix JCBC Bolt (D) into Crossbar (6) and tighten by using Allen Key (E). <b>Fully tighten all the bolts and screws now .</b></p>	
<p>7</p>	<p>With two people turn over the table carefully. Assembly completed.</p>	

**ASSEMBLY TIPS:**

Please check parts and hardware before assembling. Follow each instruction step by step.  
 Place a protective pad or piece of cardboard on the floor while assembling your item on top of it.  
 Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list.  
 Please follow instructions in the sequence as numbered to assure fast/easy assembly.

**WARNING:**

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement.  
 Keep all hardware parts out of the reach of children.

**FURNITURE CARE:**

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:  
 Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.  
 Excessive exposure to sunlight may cause fading.  
 Excessive temperature and humidity or cold may cause cracking or splitting.  
 Dust with a clean, damp, lint free cloth.  
 Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.  
 Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.