
## ASSEMBLY INSTRUCTION





Product Name: ARINDA SIDEBOARD - NATURAL


PART LIST Before you begin, please layout all parts and ensure you have the correct count.					
PART	DESCRIPTION	QUANTITY	ILLUSTRATION		
1	TOP PANEL	1			
2	BOTTOM PANEL	1			
3	SIDE PANEL	2	0 0 0		
4	CENTER PANEL	1			
5	BACK PANEL	1	0 0 0		
6	DOOR PANEL ASSY	2			
			1/9		


PART LIST Before you begin, please layout all parts and ensure you have the correct count.					
PART	DESCRIPTION	QUANTITY	ILLUSTRATION		
7	ADJUSTABLE SHELF PANEL	1			
8	METAL LEG ASSY	2			
9	METAL STRETCHER	1			
10	GROOVE COVER	2	Car and		
A	MINIFIX HOUSING Ø15	18			
В	MINIFIX BOLT LENGHT = 34 MM	18	£)=[]####		
с	DOWEL (Ø8 X 30 MM)	16			
D	JCBC BOLT (M6 X 15)	8	and the second s		
E	JMT BOLT (M4 X 10)	2	2/9		


PART LIST Before you begin, please layout all parts and ensure you have the correct count.					
PART	DESCRIPTION	QUANTITY	ILLUSTRATION		
F	SHELF PIN	4	- A A A A A A A A A A A A A A A A A A A		
G	JF SCREW (Ø6 X 12MM)	4	THUR		
Н	ALLEN KEY M4	1			
I	TIPPING HARDWARE	2			
J	FISCHER	2			











# ASSEMBLY INSTRUCTIONS

#### **ASSEMBLY TIPS:**

Please check parts and hardware before assembling. Follow each instruction step by step. Place a protective pad or piece of cardboard on the floor while assembling your item on top of it. Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list. Please follow instructions in the sequence as numbered to assure fast/easy assembly.

#### WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement. Keep all hardware parts out of the reach of children.

### FURNITURE CARE:

Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster. Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.