


Product Name: HADLEY DINING CHAIR

PARTS LIST Before you begin, please layout all parts and ensure you have the correct count.			
NO.	DESCRIPTION	QUANTITY	ILLUSTRATION
1	Back Frame	1	
2	Front Leg	1	
3	Side Stretcher (L&R)	2	
4	Side Rail	2	\int
5	Cushion Seat	1	
А	JCBC M6 x 45mm + S/W M6 + F/W M6 x 13mm	4	
В	Allen Key M4	1	
с	L Bracket	4	<u>e</u>
D	CSK Screw M3.5 x 12mm	8	~(#)
E	FH Screw #8 x 32mm	4	< <u>()</u>
F	Protective Disc 22mm	4	

ASSEMBLY INSTRUCTIONS			
STEP	DESCRIPTION	ILLUSTRATION	
1	Slot in both Side Stretcher (3R & 3L) and both Side Rail (4) into Back Frame (1) as shown. Please make sure that (3R) has a small hole for identification. Fix JCBC Bolt (A) into Side Stretcher (3R & 3L) and tighten it by using Allen Key (B). Fix FH Screw (E) into Side Rail (4) and tighten it by using Screwdriver (not provided). Do not fully tighten the bolts and screws.	(3R) has a small hole for identification.	
2	Place Front Leg (2) into Side Stretcher (3R & 3L) and Side Rail (4). Fix JCBC Bolt (A) into Side Stretcher (3R & 3L) and tighten it by using Allen Key (B). Fix FH Screw (E) into Side Rail (4) and tighten it by using Screwdriver (not provided). Do not fully tighten the bolts and screws.		
3	Place the dining chair upside down on the table, fix Cushion Seat (5) with L- Bracket (C) and CSK Screw (D) using Screwdriver (not provided). Fully tighten the bolts and screws now .		



ASSEMBLY TIPS:

Please checks parts and hardware before assembling. Follow each instruction step by step. Place a protective pad or piece of cardboard on the floor while assembling your item on top of it. Remove all parts from the carton and separate them into part numbers/groups as indicated on the part list. Please follow instructions in the sequence as numbered to assure fast/easy assembly.

WARNING:

Don't attempt to repair or modify parts that are broken or defective - if you find a broken part please contact us for replacement. Keep all hardware parts out of the reach of children.

FURNITURE CARE:

Following these few basis steps will help to ensure that you enjoy your furniture for a long time:

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster. Excessive exposure to sunlight may cause fading.

Excessive temperature and humidity or cold may cause cracking or splitting.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.